

THERMAL CONDUCTIVITY ANALYSIS

Thermal Grout Lite & Select



PLEASE COMPLETE THE ENTIRE FORM WHEN INFORMATION IS AVAILABLE

SAMPLING INSTRUCTIONS:

- 1) Fill the sample container as full as possible with a fully mixed aqueous sample.
- 2) Tightly place the lid on the sample container.
- 3) Insert the sample container into the pre-addressed return-shipping carton.
- 4) Complete this form and insert between the sample container and the shipping carton.
- 5) **Return the entire package to GeoPro, Inc. for analysis.**
- 6) A written analysis will be forwarded to the address of the initiator, provided that this form accompanies the test sample.

PROJECT AND SAMPLE INFORMATION:

Sampling Collection Date: _____ Approx. Time: _____

PROJECT: Name: _____
 Location: _____
 Total No. of Bores: _____ Bore Depth: _____ Bore Dia.: _____

RESULTS RECIPIENT INFORMATION:

Sample results will be sent to the person listed below using the selected method. U.S. Mail E-mail Fax

Design Engineer Name: _____
 Drilling Contractor Company: _____
 General Contractor Address: _____
 Building Owner City: _____ State: _____ Zip: _____
 State Regulator Phone: _____ Fax: _____
 E-Mail Address: _____

GEOPRO USE ONLY

Arrival Date: _____ Notes: _____

Test Location: _____

Test #	Date/Time	Unit	Tester	W/m °C	Btu/hr ft °F*
1		am pm			
2		am pm			
3		am pm			
4		am pm			
5		am pm			
AVERAGES					

*0.5778 Btu/ hr ft °F = 1.0 W/m °C

GEOPRO USE ONLY

SEND THIS FORM TO:

GeoPro, Inc. | 302 E. Warehouse St. | Elkton, SD 57026 | 877.580.9348 | Fax: 605.542.1303